



iMOW® 3 iMOW® 3 EVO iMOW® 4 iMOW® 4 EVO



























































































































support.stihl.com

© ANDREAS STIHL AG & Co. KG 0457 374 0006 A A25

Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries.

App Store is a service mark of Apple Inc. Google Play and the Google Play logo are trademarks of Google Inc.

